




LG VX8550 Speaker Replacement

Written By: Nathan Jones



INTRODUCTION

Steps to replace the LG VX8550 speaker

TOOLS:

- [iFixit Opening Tools](#) (1)
 - [Phillips #00 Screwdriver](#) (1)
 - [Push Pin](#) (1)
-

Step 1 — Battery




- Slide the battery release up.

Step 2



- Remove the battery by lifting away from the case.

Step 3 — Case




- Remove the 2 screw covers next to the rear speaker with a Push Pin.

Step 4



- Remove the 4 cover screws with a Philips #00 screwdriver.

Step 5



- Use the iPod opening tool to pry off the back casing.

Step 6




- Continue sliding the iPod opening tool around the seam of the casing to separate the front and back casings.


Step 7



- Separate the casing halves.


 Be sure to keep track of the side buttons as they fall out.

Step 8 — Speaker




- With the back casing removed the speaker is visible.

Step 9




- Lift up under top end of circuit board with the Spudger to access retaining clip.

Step 10




- Carefully pry up on retaining clip with the Spudger to release the speaker.

Step 11



⚠ Carefully unplug speaker connector from circuit board with your fingers.

Step 12



- Remove the speaker by lifting up.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-20 05:22:36 PM.